






PACKAGE	MODEL NO.
1 	RV-WING Digital Accessory 900-00410

2 	RV-2005 Amplified Antenna Head 900-00110 75 ohm
---	---


	3762182 Pin & C Clip 900-00180
---	--


3 	RP-2900 2 Elevator Tubes 2 Grommets 4 Pins 4 Retaining Rings Rubber Bumper Self Drilling 900-00200
--	---

5 	RP-0154 Boot 900-00150
---	--

6 	RP-3000 Elevating Gear 900-00190
---	--


7 	RP-4000 Worm Gear & 12.25" Hex Elevating Shaft Assembly w/ Wave Washer Flat Washer O Ring Worm Gear Nut 900-00220
---	--

PACKAGE	MODEL NO.
8 	RP-2048 Gear Housing 2 Pins Sealing Nut ** Bearing O-Ring Seal Retaining Ring 900-00230


9 	RP-3523 Base Plate 10 Screws Rubber Boot 900-00260
---	--


10 	RP-6300 WHITE Directional Handle Ceiling Plate 4 Screws Spring Decal 900-00300
--	---

11 	RP-6822 Spring 900-00320
--	--

12 	RP-2658 Nylon Bearing 900-00340
--	---

13 	RP-6733 WHITE Crank Set Screw 900-00350
--	---

15 	RW-2000 Roof Wedge 900-00380
--	--

17 	EK-1036 Directional Handle Extension 900-00400
--	--

* Remove/tighten with 15/16" 12 socket.
** Use 3/32 Allen Wrench for set screw.

